

Cordless Jig Saw
DJV141, DJV142



As powerful as corded Jigsaws, yet light weight



Excellent Performance Provides High Productivity

Powerful BLDC motor

provides higher operating efficiency than that of the current BLDC motor, increased max output power and work amount on a single full battery charge.







Compact, Lightweight design

Barrel handle type



2.5kg (DJV181) / 2.4kg (DJV141)

DJV181; with battery BL1840

DJV141; with battery BL1440

Electronic push button switch

located on both side of Housing

How to start the machine;

Press the button A once^{*1}, the LED light turns on, and you press the button B within 10 seconds^{*2}, the machine starts.

How to stop the machine;

Press either of the buttons A or B, the machine stops.



- *1: If you press the button A again within 10 seconds, the LED light turns off and the machine backs to the locking mode.
- *2: After 10 seconds you turned on the LED light, the light automatically turns off and the machine backs to the locking mode.

Note: The button B does not work while the machine is in the locking mode

Top handle type



2.6kg (DJV182) / 2.5kg (DJV142)

DJV182; with battery BL1840

DJV142; with battery BL1440

Trigger switch with lock-on button

provides the same maneuverability as AC models

How to start the machine;

Press Lock-off button once¹, the LED light turns on, and you pull the trigger of Switch within 10 seconds², the machine starts.

How to stop the machine;

Release Trigger switch, the machine stops.



- *1: If you press Lock-off button again within 10 seconds, the LED light turns off and the machine backs to the locking mode.
- *2: After 10 seconds you turned on the LED light, the light automatically turns off and the machine backs to the locking mode.

Note: Trigger switch does not work while the machine is in the locking mode.

LED job light (twin-light)

for illuminated operation



Toolless blade clamp

Blade can be attached with single action - simply by pushing it into the clamp;

can be also removed easily with single action - simply by turning large lever





Soft start

allows for accurate landing of the blade on the surface of workpiece in various applications.

Soft no load speed

reduces the blade stroke at a no load speed of 3,500rpm (highest speed mode) for easy trace of cutting line.

Ergonomically designed handle with soft grip

Provides comfortable grip and more control while minimizing hand fatigue and pain.

Powered by 14.4V/ 18V Li-ion batteries

- · High power density allows compact and lightweight tool design without power loss.
- Can be charged at any time because Li-ion battery is free from memory effect.

Variable speed control by dial

located on the rear side for easier operation





Dust nozzle can be attached over the sawdust exhaust port for connection to Makita vacuum cleaner.

Battery & Charger Time Reference Chart (in Minutes)

keeps the cut line clean.



DC18RC / DC18RA

Fast Charging

22min.

Fast Charging

15min.

Fast Charging





DC18SD DC18SE (Automotive)

90min. 1 to 2 batteries 180min. 3 to 4 batteries

60min. 1 to 2 batteries

60min.

90min.

30min. 1 to 2 batteries 60min. 3 to 4 batteries

120min. 3 to 4 batteries

30min.

Cordless Jig Saw

DJV141 / DJV181 DJV142 / **DJV182**



cutting with optional blade No.B-16L weight according to EPTA-Procedure 01/2003

Anti-Splintering Device, Hex Wrench Items of standard equipment and specifications may vary by country or area.



Makita Corporation